

SCHURTER
ELECTRONIC COMPONENTS

Schurter

CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S

Hlutanúmer:	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S
Framleiðandi / Vöruerki:	Schurter
Vörulýsing	SWITCH PUSHBUTTON SPST 100MA 42V
Gagnablöð:	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S.pdf
RoHS Staða	Leiða frjáls / RoHS samhæft
Ástand á lager	2875 pcs stock
Skip frá	Hong Kong
Sending vegur	DHL/Fedex/TNT/UPS/EMS

BEIÐNI UM TILVITNUN

Mynd getur verið fulltrúi. Sjá upplýsingar um upplýsingar um vörur.

Upplýsingar um CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S

HLUTANÚMER	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S
FRAMLEIÐANDI	Schurter
LÝSING	SWITCH PUSHBUTTON SPST 100MA 42V
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Leiða frjáls / RoHS samhæft
MAGN Í BODI	2875 pcs
GÖGN	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S.pdf
SPENNAHLUTFALL - DC	60V
SPENNA EINKUNN - AC	42V
GERÐ	Capacitive, Illuminated
UPPSAGNARSTÍLL	Wire Leads
ROFI VIRKA	Off-On
RÖÐ	CPS
PALLBORÐSMET	Circular - 19.10mm Dia
PÖKKUN	Bulk
VINNUHITASTIG	-40°C ~ 60°C
UPPSETNINGARTEGUND	Panel Mount, Front
VÖKTUNARN/EMISSTIG (MSL)	1 (Unlimited)
VÉLRÆN LÍF	-
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Lead free / RoHS Compliant
INNDRÁSARVÖRN	IP67 - Dust Tight, Waterproof
UPPLJÓS SPENNA (NAFNVERÐ)	5 ~ 28 VDC
LÝSING LÝSINGAR, LIT.	LED, Blue
LÖGUN	Arrow Symbol
RAFMAGNSLÍF	-
NÁKVÆM LÝSING	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
NÚVERANDI EINKUNN	100mA (AC/DC)
LITUR - STÝRISBÚNAÐUR / LOKI	Silver
HRINGRÁS	SPST
VIRKJUNARGERÐ	Round, Button, Flush

Svipaðir merkingar

Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S dreifingaraðili	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S Birgir
CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S Verð	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S Myndir	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S Image
CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S PDF skjal	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S Sækja gagnapakann	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S gagnablöð
CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S lager	Kaupa CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S	Kaupa Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S
Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S	Schurter Birgir	Schurter dreifingaraðili
Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S	Schurter Inc. CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S	

skyldar vörur

<div style="border: 1px solid #ccc; padding: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <div> <p style="color: #0056b3; font-weight: bold;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1050-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 5001 pcs</p> <p style="background-color: #ccc; padding: 2px 5px; text-align: center; font-weight: bold;">RFQ</p> </div> </div> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <div> <p style="color: #0056b3; font-weight: bold;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1052-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 6544 pcs</p> <p style="background-color: #ccc; padding: 2px 5px; text-align: center; font-weight: bold;">RFQ</p> </div> </div> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <div> <p style="color: #0056b3; font-weight: bold;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 3821 pcs</p> <p style="background-color: #ccc; padding: 2px 5px; text-align: center; font-weight: bold;">RFQ</p> </div> </div> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <div> <p style="color: #0056b3; font-weight: bold;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1042-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 5100 pcs</p> <p style="background-color: #ccc; padding: 2px 5px; text-align: center; font-weight: bold;">RFQ</p> </div> </div> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <div> <p style="color: #0056b3; font-weight: bold;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1043-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 7063 pcs</p> <p style="background-color: #ccc; padding: 2px 5px; text-align: center; font-weight: bold;">RFQ</p> </div> </div> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <div> <p style="color: #0056b3; font-weight: bold;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1041-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 4360 pcs</p> <p style="background-color: #ccc; padding: 2px 5px; text-align: center; font-weight: bold;">RFQ</p> </div> </div> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <div> <p style="color: #0056b3; font-weight: bold;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1044-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 3717 pcs</p> <p style="background-color: #ccc; padding: 2px 5px; text-align: center; font-weight: bold;">RFQ</p> </div> </div> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <div> <p style="color: #0056b3; font-weight: bold;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 5540 pcs</p> <p style="background-color: #ccc; padding: 2px 5px; text-align: center; font-weight: bold;">RFQ</p> </div> </div> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <div> <p style="color: #0056b3; font-weight: bold;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1049-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 6639 pcs</p> <p style="background-color: #ccc; padding: 2px 5px; text-align: center; font-weight: bold;">RFQ</p> </div> </div> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <div> <p style="color: #0056b3; font-weight: bold;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1048-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 5276 pcs</p> <p style="background-color: #ccc; padding: 2px 5px; text-align: center; font-weight: bold;">RFQ</p> </div> </div> </div>
<div style="border: 1px solid #ccc; padding: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <div> <p style="color: #0056b3; font-weight: bold;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1051-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 3195 pcs</p> <p style="background-color: #ccc; padding: 2px 5px; text-align: center; font-weight: bold;">RFQ</p> </div> </div> </div>	<div style="border: 1px solid #ccc; padding: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <div> <p style="color: #0056b3; font-weight: bold;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1040-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 6794 pcs</p> <p style="background-color: #ccc; padding: 2px 5px; text-align: center; font-weight: bold;">RFQ</p> </div> </div> </div>