

SCHURTER
ELECTRONIC COMPONENTS

Schurter

CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S

| | |
|--------------------------|--|
| Hlutanúmer: | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S |
| Framleiðandi / Vöruerki: | Schurter |
| Vörulýsing | SWITCH PUSHBUTTON SPST 100MA 42V |
| Gagnablöð: | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S.pdf |
| RoHS Staða | Leiða frjáls / RoHS samhæft |
| Ástand á lager | 6380 pcs stock |
| Skip frá | Hong Kong |
| Sending vegur | DHL/Fedex/TNT/UPS/EMS |

BEIÐNI UM TILVITNUN

Mynd getur verið fulltrúi. Sjá upplýsingar um upplýsingar um vörur.

Upplýsingar um CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S

| | |
|---------------------------------|---|
| HLUTANÚMER | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S |
| FRAMLEIÐANDI | Schurter |
| LÝSING | SWITCH PUSHBUTTON SPST 100MA 42V |
| LEIDA FRJÁLS STAÐA / ROHS STAÐA | Leiða frjáls / RoHS samhæft |
| MAGN Í BODI | 6380 pcs |
| GÖGN | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S.pdf |
| SPENNAHLUTFALL - DC | 60V |
| SPENNA EINKUNN - AC | 42V |
| GERÐ | Capacitive, Illuminated |
| UPPSAGNARSTÍLL | Wire Leads |
| ROFI VIRKA | Off-On |
| RÖÐ | CPS |
| PALLBORÐSMET | Circular - 19.10mm Dia |
| PÖKKUN | Bulk |
| VINNUHITASTIG | -40°C ~ 60°C |
| UPPSETNINGARTEGUND | Panel Mount, Front |
| VÖKTUNARN/EMISSTIG (MSL) | 1 (Unlimited) |
| VÉLRÆN LÍF | - |
| LEIDA FRJÁLS STAÐA / ROHS STAÐA | Lead free / RoHS Compliant |
| INNRSÁRVÖRN | IP67 - Dust Tight, Waterproof |
| UPPLJÓS SPENNA (NAFNVERÐ) | 5 ~ 28 VDC |
| LÝSING LÝSINGAR, LIT. | LED, Blue |
| LÖGUN | Decimal Symbol |
| RAFMAGNLÍF | - |
| NÁKVÆM LÝSING | Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front |
| NÚVERANDI EINKUNN | 100mA (AC/DC) |
| LITUR - STÝRISBÚNAÐUR / LOKI | Silver |
| HRINGRÁS | SPST |
| VIRKJUNARGERÐ | Round, Button, Flush |

Svipaðir merkingar

| | | |
|--|--|---|
| Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S dreifingaraðili | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S Birgir |
| CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S Verð | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S Myndir | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S Image |
| CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S PDF skjal | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S Sækja gagnapakann | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S gagnablöð |
| CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S lager | Kaupa CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S | Kaupa Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S |
| Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S | Schurter Birgir | Schurter dreifingaraðili |
| Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S | Schurter Inc. CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S | |

skyldar vörur

| | |
|---|---|
| <div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1035-S</p> <p style="margin: 0; font-size: small;">Framleiðendur: Schurter</p> <p style="margin: 0; font-size: small;">Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p style="margin: 0; font-size: small;">Á lager: 2909 pcs</p> <p style="text-align: center; margin: 5px 0;">RFQ</p> </div> | <div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1040-S</p> <p style="margin: 0; font-size: small;">Framleiðendur: Schurter</p> <p style="margin: 0; font-size: small;">Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p style="margin: 0; font-size: small;">Á lager: 6794 pcs</p> <p style="text-align: center; margin: 5px 0;">RFQ</p> </div> |
| <div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S</p> <p style="margin: 0; font-size: small;">Framleiðendur: Schurter</p> <p style="margin: 0; font-size: small;">Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p style="margin: 0; font-size: small;">Á lager: 3821 pcs</p> <p style="text-align: center; margin: 5px 0;">RFQ</p> </div> | <div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1042-S</p> <p style="margin: 0; font-size: small;">Framleiðendur: Schurter</p> <p style="margin: 0; font-size: small;">Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p style="margin: 0; font-size: small;">Á lager: 5100 pcs</p> <p style="text-align: center; margin: 5px 0;">RFQ</p> </div> |
| <div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1037-S</p> <p style="margin: 0; font-size: small;">Framleiðendur: Schurter</p> <p style="margin: 0; font-size: small;">Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p style="margin: 0; font-size: small;">Á lager: 6994 pcs</p> <p style="text-align: center; margin: 5px 0;">RFQ</p> </div> | <div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1036-S</p> <p style="margin: 0; font-size: small;">Framleiðendur: Schurter</p> <p style="margin: 0; font-size: small;">Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p style="margin: 0; font-size: small;">Á lager: 6392 pcs</p> <p style="text-align: center; margin: 5px 0;">RFQ</p> </div> |
| <div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1033-S</p> <p style="margin: 0; font-size: small;">Framleiðendur: Schurter</p> <p style="margin: 0; font-size: small;">Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p style="margin: 0; font-size: small;">Á lager: 5301 pcs</p> <p style="text-align: center; margin: 5px 0;">RFQ</p> </div> | <div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1034-S</p> <p style="margin: 0; font-size: small;">Framleiðendur: Schurter</p> <p style="margin: 0; font-size: small;">Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p style="margin: 0; font-size: small;">Á lager: 3896 pcs</p> <p style="text-align: center; margin: 5px 0;">RFQ</p> </div> |
| <div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1044-S</p> <p style="margin: 0; font-size: small;">Framleiðendur: Schurter</p> <p style="margin: 0; font-size: small;">Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p style="margin: 0; font-size: small;">Á lager: 3717 pcs</p> <p style="text-align: center; margin: 5px 0;">RFQ</p> </div> | <div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1043-S</p> <p style="margin: 0; font-size: small;">Framleiðendur: Schurter</p> <p style="margin: 0; font-size: small;">Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p style="margin: 0; font-size: small;">Á lager: 7063 pcs</p> <p style="text-align: center; margin: 5px 0;">RFQ</p> </div> |
| <div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1038-S</p> <p style="margin: 0; font-size: small;">Framleiðendur: Schurter</p> <p style="margin: 0; font-size: small;">Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p style="margin: 0; font-size: small;">Á lager: 5571 pcs</p> <p style="text-align: center; margin: 5px 0;">RFQ</p> </div> | <div style="border: 1px solid #ccc; padding: 5px;"> <p style="margin: 0;">CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1041-S</p> <p style="margin: 0; font-size: small;">Framleiðendur: Schurter</p> <p style="margin: 0; font-size: small;">Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p style="margin: 0; font-size: small;">Á lager: 4360 pcs</p> <p style="text-align: center; margin: 5px 0;">RFQ</p> </div> |