

Schurter

CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S

Hlutanúmer:	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S
Framleiðandi / Vörumerki:	Schurter
Vörulýsing	SWITCH PUSH SPST-NO 100MA 42V
Gagnablið:	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S.pdf
RoHS Staða	Leiða frjálts / RoHS samhæft
Ástand á lager	5430 pcs stock
Skip frá	Hong Kong
Sending vegur	DHL/Fedex/TNT/UPS/EMS

BEIÐNI UM TILVITNUN

Mynd getur verið fulltrúi. Sjá upplýsingar um upplýsingar um vörur.

Upplýsingar um CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S

HLUTANÚMER	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S
FRAMLEIÐANDI	Schurter
LÝSING	SWITCH PUSH SPST-NO 100MA 42V
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Leiða frjálts / RoHS samhæft
MAGN Í BODI	5430 pcs
GÖGN	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S.pdf
SPENNAHLUTFALL - DC	60V
SPENNA EINKUNN - AC	42V
GERÐ	Capacitive, Illuminated
UPPSAGNARSTÍLL	Wire Leads
ROFI VIRKA	Off-Mom
RÖÐ	CPS
PALLBORÐSMET	Circular - 16.10mm Dia
PÖKKUN	Bulk
VINNUHITASTIG	-40°C ~ 60°C
UPPSETNINGARTEGUND	Panel Mount, Front
VÖKTUNARN/EMISSTIG (MSL)	1 (Unlimited)
VÉLRÆN LÍF	-
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Lead free / RoHS Compliant
INNDRÁSARVÖRN	IP67 - Dust Tight, Waterproof
UPPLJÓS SPENNA (NAFNVERÐ)	5 ~ 28 VDC
LÝSING LÝSINGAR, LIT.	LED, White
LÖGUN	Ceramic Actuator, Finger Guide, RESET Symbol
RAFMAGNSLÍF	-
NÁKVÆM LÝSING	Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front
NÚVERANDI EINKUNN	100mA (AC/DC)
LITUR - STÝRISBÚNAÐUR / LOKI	Clear (White Filter/Diffuser)
HRINGRÁS	SPST-NO
VIRKJUNARGERÐ	Round, Button, Flush

Svipaðir merkingar

Schurter CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S dreifingaraðili	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S Birgir
CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S Verð	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S Myndir	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S Image
CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S PDF skjal	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S Sækja gagnapakkann	CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S gagnablið
CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S lager	Kaupa CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S	Kaupa Schurter CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S
Schurter CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S	Schurter Birgir	Schurter dreifingaraðili
Schurter CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S	Schurter Inc. CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1073-S	

skyldar vörur

<p>CPS16-NO00A10-SNCCWTWF-AIOWYVAR-W1001-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 5161 pcs</p> <p style="background-color: #ccc; padding: 2px; text-align: center; font-weight: bold;">RFQ</p>	<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1067-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 4262 pcs</p> <p style="background-color: #ccc; padding: 2px; text-align: center; font-weight: bold;">RFQ</p>
<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1074-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 4512 pcs</p> <p style="background-color: #ccc; padding: 2px; text-align: center; font-weight: bold;">RFQ</p>	<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1072-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 5495 pcs</p> <p style="background-color: #ccc; padding: 2px; text-align: center; font-weight: bold;">RFQ</p>
<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1069-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 2986 pcs</p> <p style="background-color: #ccc; padding: 2px; text-align: center; font-weight: bold;">RFQ</p>	<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1070-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 5123 pcs</p> <p style="background-color: #ccc; padding: 2px; text-align: center; font-weight: bold;">RFQ</p>
<p>CPS16-NO00A10-SNCCWTWF-AIOWYVAR-W0000-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 4178 pcs</p> <p style="background-color: #ccc; padding: 2px; text-align: center; font-weight: bold;">RFQ</p>	<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1075-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 4247 pcs</p> <p style="background-color: #ccc; padding: 2px; text-align: center; font-weight: bold;">RFQ</p>
<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1071-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 6014 pcs</p> <p style="background-color: #ccc; padding: 2px; text-align: center; font-weight: bold;">RFQ</p>	<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1068-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 7014 pcs</p> <p style="background-color: #ccc; padding: 2px; text-align: center; font-weight: bold;">RFQ</p>
<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1076-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 5469 pcs</p> <p style="background-color: #ccc; padding: 2px; text-align: center; font-weight: bold;">RFQ</p>	<p>CPS16-NO00A10-SNCCWTWF-AIOWTVAR-W1077-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 7006 pcs</p> <p style="background-color: #ccc; padding: 2px; text-align: center; font-weight: bold;">RFQ</p>