

Schurter

CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S

| | |
|--------------------------|--|
| Hlutanúmer: | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S |
| Framleiðandi / Vöruerki: | Schurter |
| Vörulýsing | SWITCH PUSHBUTTON SPST 100MA 42V |
| Gagnablöð: | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S.pdf |
| RoHS Staða | Leiða frjáls / RoHS samhæft |
| Ástand á lager | 5540 pcs stock |
| Skip frá | Hong Kong |
| Sending vegur | DHL/Fedex/TNT/UPS/EMS |

BEIÐNI UM TILVITNUN

Mynd getur verið fulltrúi. Sjá upplýsingar um upplýsingar um vörur.

Upplýsingar um CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S

| | |
|---------------------------------|---|
| HLUTANÚMER | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S |
| FRAMLEIÐANDI | Schurter |
| LÝSING | SWITCH PUSHBUTTON SPST 100MA 42V |
| LEIDA FRJÁLS STAÐA / ROHS STAÐA | Leiða frjáls / RoHS samhæft |
| MAGN Í BODI | 5540 pcs |
| GÖGN | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S.pdf |
| SPENNAHLUTFALL - DC | 60V |
| SPENNA EINKUNN - AC | 42V |
| GERÐ | Capacitive, Illuminated |
| UPPSAGNARSTÍLL | Wire Leads |
| ROFI VIRKA | Off-On |
| RÖÐ | CPS |
| PALLBORÐSMET | Circular - 19.10mm Dia |
| PÖKKUN | Bulk |
| VINNUHITASTIG | -40°C ~ 60°C |
| UPPSETNINGARTEGUND | Panel Mount, Front |
| VÖKTUNARN/EMISSTIG (MSL) | 1 (Unlimited) |
| VÉLRÆN LÍF | - |
| LEIDA FRJÁLS STAÐA / ROHS STAÐA | Lead free / RoHS Compliant |
| INNRSÁRVÖRN | IP67 - Dust Tight, Waterproof |
| UPPLJÓS SPENNA (NAFNVERÐ) | 5 ~ 28 VDC |
| LÝSING LÝSINGAR, LIT. | LED, Blue |
| LÖGUN | Arrow Symbol |
| RAFMAGNSLÍF | - |
| NÁKVÆM LÝSING | Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front |
| NÚVERANDI EINKUNN | 100mA (AC/DC) |
| LITUR - STÝRISBÚNAÐUR / LOKI | Silver |
| HRINGRÁS | SPST |
| VIRKJUNARGERÐ | Round, Button, Flush |

Svipaðir merkingar

| | | |
|--|--|---|
| Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S dreifingaraðili | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S Birgir |
| CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S Verð | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S Myndir | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S Image |
| CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S PDF skjal | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S Sækja gagnapakann | CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S gagnablöð |
| CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S lager | Kaupa CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S | Kaupa Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S |
| Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S | Schurter Birgir | Schurter dreifingaraðili |
| Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S | Schurter Inc. CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S | |

skyldar vörur

| | |
|--|--|
| <p>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 2875 pcs</p> <p>RFQ</p> | <p>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1048-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 5276 pcs</p> <p>RFQ</p> |
| <p>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 3821 pcs</p> <p>RFQ</p> | <p>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1044-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 3717 pcs</p> <p>RFQ</p> |
| <p>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1042-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 5100 pcs</p> <p>RFQ</p> | <p>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1049-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 6639 pcs</p> <p>RFQ</p> |
| <p>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1053-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 3169 pcs</p> <p>RFQ</p> | <p>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1043-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 7063 pcs</p> <p>RFQ</p> |
| <p>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1050-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 5001 pcs</p> <p>RFQ</p> | <p>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1041-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 4360 pcs</p> <p>RFQ</p> |
| <p>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1051-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 3195 pcs</p> <p>RFQ</p> | <p>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1052-S</p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 6544 pcs</p> <p>RFQ</p> |

Höfundarréttur © 2020 Áreiðanleg dreifingaraðili rafeindabúnaðar

Tölvupóstur: Info@infinity-electronic.com

Heimilisfang: 17F, Gaylord Commercial Building, 114-118 Lockhart Road, Wan Chai, Hong Kong

