





Schurter




CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S

Hlutanúmer:	CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S
Framleiðandi / Vörumerki:	Schurter
Vörulýsing	SWITCH PUSHBUTTON SPST 100MA 42V
Gagnablöð:	 CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S.pdf
RoHS Staða	 Leiða frjáls / RoHS samhæft
Ástand á lager	3418 pcs stock
Skip frá	Hong Kong
Sending vegur	DHL/Fedex/TNT/UPS/EMS

BEIÐNI UM TILVITNUN

Mynd getur verið fulltrúi. Sjá upplýsingar um upplýsingar um vörur.




Upplýsingar um CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S

HLUTANÚMER	CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S
FRAMLEIÐANDI	Schurter
LÝSING	SWITCH PUSHBUTTON SPST 100MA 42V
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Leiða frjáls / RoHS samhæft
MAGN Í BODI	3418 pcs
GÖGN	 CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S.pdf
SPENNAHLUTFALL - DC	60V
SPENNA EINKUNN - AC	42V
GERÐ	Capacitive, Illuminated
UPPSAGNARSTÍLL	Wire Leads
ROFI VIRKA	Off-On
RÖÐ	CPS
PALLBORÐSMET	Circular - 16.10mm Dia
PÖKKUN	Bulk
VINNUHITASTIG	-40°C ~ 60°C
UPPSETNINGARTEGUND	Panel Mount, Front
VÖKTUNARN/EMISSTIG (MSL)	1 (Unlimited)
VÉLRÆN LÍF	-
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Lead free / RoHS Compliant
INNÉRÁSRVÖRN	IP67 - Dust Tight, Waterproof
UPPLJÓS SPENNA (NAFNVERÐ)	5 ~ 28 VDC
LÝSING LÝSINGAR, LIT.	LED, Red/Blue
LÖGUN	Ceramic Actuator, Finger Guide, Q Symbol
RAFMAGNSLÍF	-
NÁKVÆM LÝSING	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
NÚVERANDI EINKUNN	100mA (AC/DC)
LITUR - STÝRISBÚNAÐUR / LOKI	Clear (White Filter/Diffuser)
HRINGRÁS	SPST
VIRKJUNARGERÐ	Round, Button, Flush

Svipaðir merkingar

Schurter CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S	CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S dreifingaraðili	CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S Birgir
CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S Verð	CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S Myndir	CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S Image
CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S PDF skjal	CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S Sækja gagnapakann	CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S gagnablöð
CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S lager	Kaupa CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S	Kaupa Schurter CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S
Schurter CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S	Schurter Birgir	Schurter dreifingaraðili
Schurter CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S	Schurter Inc. CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1017-S	

skyldar vörur

 <p>CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1021-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: 6739 pcs</p> <p style="text-align: center; background-color: #eee; padding: 2px;">RFQ</p>	 <p>CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1013-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: 4720 pcs</p> <p style="text-align: center; background-color: #eee; padding: 2px;">RFQ</p>
 <p>CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1020-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: 6219 pcs</p> <p style="text-align: center; background-color: #eee; padding: 2px;">RFQ</p>	 <p>CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1018-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: 3091 pcs</p> <p style="text-align: center; background-color: #eee; padding: 2px;">RFQ</p>
 <p>CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1022-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: 6512 pcs</p> <p style="text-align: center; background-color: #eee; padding: 2px;">RFQ</p>	 <p>CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1019-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: 4794 pcs</p> <p style="text-align: center; background-color: #eee; padding: 2px;">RFQ</p>
 <p>CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1015-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: 6003 pcs</p> <p style="text-align: center; background-color: #eee; padding: 2px;">RFQ</p>	 <p>CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1011-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: 3677 pcs</p> <p style="text-align: center; background-color: #eee; padding: 2px;">RFQ</p>
 <p>CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1014-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: 4876 pcs</p> <p style="text-align: center; background-color: #eee; padding: 2px;">RFQ</p>	 <p>CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1012-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: 5919 pcs</p> <p style="text-align: center; background-color: #eee; padding: 2px;">RFQ</p>
 <p>CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1016-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: 3696 pcs</p> <p style="text-align: center; background-color: #eee; padding: 2px;">RFQ</p>	 <p>CPS16-LA00A10-SNCCWTWF-AI0RBVAR-W1023-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V Á lager: 6787 pcs</p> <p style="text-align: center; background-color: #eee; padding: 2px;">RFQ</p>