



## CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S

Hlutanúmer:	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S
Framleiðandi / Vöruerki:	Schurter
Vörulýsing	SWITCH PUSHBUTTON SPST 100MA 42V
Gagnablöð:	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S.pdf
RoHS Staða	Leiða frjáls / RoHS samhæft
Ástand á lager	3821 pcs stock
Skip frá	Hong Kong
Sending vegur	DHL/Fedex/TNT/UPS/EMS

**BEIÐNI UM TILVITNUN**

Mynd getur verið fulltrúi. Sjá upplýsingar um upplýsingar um vörur.

### Upplýsingar um CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S

HLUTANÚMER	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S
FRAMLEIÐANDI	Schurter
LÝSING	SWITCH PUSHBUTTON SPST 100MA 42V
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Leiða frjáls / RoHS samhæft
MAGN Í BODI	3821 pcs
GÖGN	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S.pdf
SPENNAHLUTFALL - DC	60V
SPENNA EINKUNN - AC	42V
GERÐ	Capacitive, Illuminated
UPPSAGNARSTÍLL	Wire Leads
ROFI VIRKA	Off-On
RÖÐ	CPS
PALLBORÐSMET	Circular - 19.10mm Dia
PÖKKUN	Bulk
VINNUHITASTIG	-40°C ~ 60°C
UPPSETNINGARTEGUND	Panel Mount, Front
VÖKTUNARN/EMISSTIG (MSL)	1 (Unlimited)
VÉLRÆN LÍF	-
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Lead free / RoHS Compliant
INNÁRÁSRVÖRN	IP67 - Dust Tight, Waterproof
UPPLJÓS SPENNA (NAFNVERÐ)	5 ~ 28 VDC
LÝSING LÝSINGAR, LIT.	LED, Blue
LÖGUN	Arrow Symbol
RAFMAGNSLÍF	-
NÁKVÆM LÝSING	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
NÚVERANDI EINKUNN	100mA (AC/DC)
LITUR - STÝRISBÚNAÐUR / LOKI	Silver
HRINGRÁS	SPST
VIRKJUNARGERÐ	Round, Button, Flush

### Svipaðir merkingar

Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S dreifingaraðili	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S Birgir
CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S Verð	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S Myndir	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S Image
CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S PDF skjal	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S Sækja gagnapakann	CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S gagnablöð
CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S lager	Kaupa CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S	Kaupa Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S
Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S	Schurter Birgir	Schurter dreifingaraðili
Schurter CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S	Schurter Inc. CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1045-S	

### skyldar vörur

<p><b>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1043-S</b></p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 7063 pcs</p> <p><b>RFQ</b></p>	<p><b>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1050-S</b></p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 5001 pcs</p> <p><b>RFQ</b></p>
<p><b>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1046-S</b></p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 2875 pcs</p> <p><b>RFQ</b></p>	<p><b>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1039-S</b></p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 6380 pcs</p> <p><b>RFQ</b></p>
<p><b>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1047-S</b></p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 5540 pcs</p> <p><b>RFQ</b></p>	<p><b>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1041-S</b></p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 4360 pcs</p> <p><b>RFQ</b></p>
<p><b>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1049-S</b></p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 6639 pcs</p> <p><b>RFQ</b></p>	<p><b>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1048-S</b></p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 5276 pcs</p> <p><b>RFQ</b></p>
<p><b>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1044-S</b></p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 3717 pcs</p> <p><b>RFQ</b></p>	<p><b>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1051-S</b></p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 3195 pcs</p> <p><b>RFQ</b></p>
<p><b>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1040-S</b></p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 6794 pcs</p> <p><b>RFQ</b></p>	<p><b>CPS19-LA00A10-SNCSNCF-RI0BLVAR-W1042-S</b></p> <p>Framleiðendur: Schurter</p> <p>Lýsing: SWITCH PUSHBUTTON SPST 100MA 42V</p> <p>Á lager: 5100 pcs</p> <p><b>RFQ</b></p>