



CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S

Hlutanúmer:	CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S
Framleiðandi / Vörumerki:	Schurter
Vörulýsing	SWITCH PUSH SPST-NO 100MA 42V
Gagnablöð:	CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S.pdf
RoHS Staða	Leiða frjálts / RoHS samhæft
Ástand á lager	2938 pcs stock
Skip frá	Hong Kong
Sending vegur	DHL/Fedex/TNT/UPS/EMS

BEIÐNI UM TILVITNUN

Mynd getur verið fulltrúi. Sjá upplýsingar um upplýsingar um vörur.

Upplýsingar um CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S

HLUTANÚMER	CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S
FRAMLEIÐANDI	Schurter
LÝSING	SWITCH PUSH SPST-NO 100MA 42V
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Leiða frjálts / RoHS samhæft
MAGN Í BODI	2938 pcs
GÖGN	CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S.pdf
SPENNAHLUTFALL - DC	60V
SPENNA EINKUNN - AC	42V
GERÐ	Capacitive, Illuminated
UPPSAGNARSTÍLL	Wire Leads
ROFI VIRKA	Off-Mom
RÖÐ	CPS
PALLBORÐSMET	Circular - 19.10mm Dia
PÖKKUN	Bulk
VINNUHITASTIG	-40°C ~ 60°C
UPPSETNINGARTEGUND	Panel Mount, Front
VÖKTUNARN/EMISSTIG (MSL)	1 (Unlimited)
VÉLRÆN LÍF	-
LEIDA FRJÁLS STAÐA / ROHS STAÐA	Lead free / RoHS Compliant
INNÉRÁSRVÖRN	IP67 - Dust Tight, Waterproof
UPPLJÓS SPENNA (NAFNVERÐ)	5 ~ 28 VDC
LÝSING LÝSINGAR, LIT.	LED, Cyan/Red
LÖGUN	Ceramic Actuator, Finger Guide, Add Symbol
RAFMAGNSLÍF	-
NÁKVÆM LÝSING	Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front
NÚVERANDI EINKUNN	100mA (AC/DC)
LITUR - STÝRISBÚNAÐUR / LOKI	Clear (White Filter/Diffuser)
HRINGRÁS	SPST-NO
VIRKJUNARGERÐ	Round, Button, Flush

Svipaðir merkingar

Schurter CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S	CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S dreifingaraðili	CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S Birgir
CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S Verð	CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S Myndir	CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S Image
CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S PDF skjal	CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S Sækja gagnapakkan	CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S gagnablöð
CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S lager	Kaupa CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S	Kaupa Schurter CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S
Schurter CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S	Schurter Birgir	Schurter dreifingaraðili
Schurter CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S	Schurter Inc. CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1037-S	

skyldar vörur

<p>CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1031-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 5806 pcs</p> <p>RFQ</p>	<p>CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1032-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 5416 pcs</p> <p>RFQ</p>
<p>CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1036-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 5195 pcs</p> <p>RFQ</p>	<p>CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1035-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 3628 pcs</p> <p>RFQ</p>
<p>CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1043-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 2764 pcs</p> <p>RFQ</p>	<p>CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1038-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 4554 pcs</p> <p>RFQ</p>
<p>CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1039-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 4226 pcs</p> <p>RFQ</p>	<p>CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1040-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 3924 pcs</p> <p>RFQ</p>
<p>CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1033-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 4101 pcs</p> <p>RFQ</p>	<p>CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1042-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 6355 pcs</p> <p>RFQ</p>
<p>CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1041-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 4439 pcs</p> <p>RFQ</p>	<p>CPS19-NO00A10-SNCCWTWF-AI0CRVAR-W1034-S</p> <p>Framleiðendur: Schurter Lýsing: SWITCH PUSH SPST-NO 100MA 42V Á lager: 3129 pcs</p> <p>RFQ</p>